

METEX® E-345

Smut Electrocleaner for Steel

Product Code: 110245

DESCRIPTION

Metex E-345 is a dry, dustless powder formulated for smut and oxide removal from ferrous metals. It contains a unique combination of chelating and surface active agents which give the maximum in detergency and smut removal from steel.

Metex E-345 is tolerant to hard water conditions and exhibits no loss of detergency when under adverse water conditions.

Metex E-345 is ideally suited for electrocleaning of high finish steels to produce clarity of subsequent electrodeposit. When roughness or clouds are caused by smut, this electrocleaner will help eliminate this source of trouble.

Metex E-345 may be used with periodic reversal for difficult smut removal jobs.

READ ENTIRE TECHNICAL DATA SHEET BEFORE USING THIS PRODUCT

OPERATING CONDITIONS

Concentration Time

Temperature

8 to 16 oz/gal (60 - 120 g/L) 1 to 5 minutes 180-200°F (82-93°C)

SUGGESTED CYCLE

Α.

- 1. Soak clean, Metex T-103, (Data Sheet No. 0113).
- 2. Rinse.
- 3. Metex E-345, 8 12 oz/gal, (60 90 g/L) anodic, 180° 200 °F (82° 93°C).
- 4. Rinse.
- 5. Metex Acid Salt M-629, 1 lb/gal (120 g/L) room temperature, (Data Sheet No. 3001).
- 6. Rinse.
- 7. Electroplate.



Β.

- 1. Soak clean, Metex T-103.
- 2. Rinse.
- 3. Metex E-345, 12 16 oz/gal, (90 120 g/L) 180° 200°F (82° 93°C) periodic reverse current.
- 4. Rinse.
- 5. Metex Acid Salt M-629, 1 to 2 lb/gal (120 240 g/L).
- 6. Rinse.
- 7. Electroplate.

* For extremely smutty work, cathodic current can be applied on Metex M-629.

CONTROL

Direct Titration

Use 10 mL sample and 0.5N acid with phenolphthalein as indicator.

mLs 0.5N acid x .378 = oz/gal E-345 (mLs 0.5N acid x 2.831 = g/L E-345)

drops x 0.57 = oz/gal E-345 (# drops x 4.3 = g/L E-345)

EQUIPMENT

Tank and Heater Steel

Oil Trap and Dam Overflow Advisable

Ventilation Recommended

Voltage, D. C. 6 to 9

P.R. Unit If necessary



SAFETY & WARNING

MacDermid Enthone recommends that the company/operator read and review the Safety Data Sheets for the appropriate health and safety warnings before use.

Safety Data Sheets are available from MacDermid Enthone.

WASTE TREATMENT

Prior to using any recommendations or suggestions by MacDermid Enthone for waste treatment, the user is required to know the appropriate local/state/federal regulations for on-site or off-site treatment which may require permits. If there is any conflict regarding our recommendations, local/state/federal regulations take precedent.

ORDER INFORMATION

Product	Code
METEX E-345	110245

CONTACT INFORMATION

To confirm this is the most recent issue, please contact MacDermid Enthone

macdermidenthone.com/industrial

North America 245 Freight Street Waterbury, CT 06702, USA 203.575.5700 americas@macdermidenthone.com

Also read carefully warning and safety information on the Safety Data Sheet. This data sheet contains technical information required for safe and economical operation of this product. READ IT THOROUGHLY PRIOR TO PRODUCT USE. Emergency safety directory assistance: US 1 202 464 2554, Europe + 44 1235 239 670, Asia + 65 3158 1074, Brazil 0800 707 7022 and 0800 172 020, Mexico 01800 002 1400 and (55) 5559 1588

DISCLAIMER: All statements, technical information and recommendations contained herein are based on tests we believe to be reliable, but the accuracy or completeness thereof is not guaranteed. No statement or recommendation shall constitute a representation unless set forth in an agreement signed by officers of seller and manufacturer. NO WARRANTY OF MERCHANTABILITY, WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OR ANY IMPLIED WARRANTY IS MADE. The following warranty is made in lieu of such warranties and all other warranties, express, implied, or statutory. Products are warranted to be free from defects in material and workmanship at the time sold. The sole obligation of seller and manufacturer under this warranty shall be to replace any noncompliant product at the time sold. Under no circumstances shall manufacturer or seller be liable for any loss, damage or expense, direct, indirect, incidental or consequential, arising out of the inability to use the product. Notwithstanding the foregoing, if products are supplied in response to a customer request that specifies operating parameters beyond those stated above, or if products are used under conditions exceeding said parameters, the customer by acceptance or use thereof assumes all risk of product failure and of all direct, indirect, incidental and consequential damages that may result from use of the products under such conditions, and agrees to exonerate, indemnify, defend and hold harmless MacDermid, Incorporated and its affiliates thereform. No suggestion for product use nor anything contained herein shall be construed as a recommendation to use any product in a manufacturer assume no responsibility or ilability or any such infringement.

© 2019 MacDermid, Inc. and its group of companies. All rights reserved. "(R)" and "TM" are registered trademarks or trademarks of MacDermid, Inc. and its group of companies in the United States and/or other countries.